



Divercleanse



Hospital Grade Disinfectant

Description

Divercleanse is a one-step cleaning and Hospital Grade Disinfectant agent which can be used for cleaning and disinfecting.

It is suitable for use in shower recesses, bathrooms, washrooms, on tiles, floors and other healthcare environmental hard surfaces.

Divercleanse is a chlorine-based (sodium hypochlorite) agent and needs to be diluted for use.

Features

- Divercleanse is a Hospital Grade Disinfectant.
- Eliminates mould and bacteria.
- Cleans, disinfects and deodorises.
- Removes unpleasant smells.
- Kills COVID-19 and MRSA in 1 minute.
- Kills E. coli, S. aureus, P. aeruginosa and P. vulgaris.

Benefits

- Highly versatile chlorine based cleaning and disinfecting agent specially designed to cling onto sloping or vertical surfaces such as shower recesses, and includes surfactants and deodorising properties to enhance cleaning and control odour

Application areas

- Lodging
- Office Buildings
- Education
- Healthcare
- Retail



AUST L - 402270



Divercleanse



Hospital Grade Disinfectant

Directions for use

Healthcare settings

When used in healthcare settings follow the facility policies and procedures for required concentration (i.e. parts per million [ppm]) for general purpose cleaning, sanitising and/or cleaning and disinfection.

Volume of Divercleanse to water to give the required chlorine concentration

Final volume of solution	100ppm	200ppm	1000ppm	5000ppm	10000ppm
750ml	3ml	5ml	27ml	128ml	252ml
5L	18ml	35ml	175ml	850ml	1.7L
10L	36ml	70ml	350ml	1.7L	3.4L

Prepare desired solution according to the table above. Apply diluted Divercleanse solution to surface. Scrub or wipe over surface. Rinse.

Use undiluted to remove mould, stains and odour.

To kill COVID-19 and MRSA, prepare 5000ppm solution (see table above for preparation). Apply to surface, allow 1min contact time. Rinse.

For use as a Hospital Grade Disinfectant, prepare a 1:4 solution (128ml per 750ml of solution). Apply to surface and leave for 10minutes. Rinse.

Hard surface disinfectant only. Not to be used on skin. Not to be used on medical devices or other therapeutic goods.

Store below 25°C. Discard diluted solutions after use.

In New Zealand: MPI Approved C32 (All animal product except dairy).



Divercleanse

Technical data

Appearance	Pale, yellow liquid	Specific gravity (20°C)	1.08
Odour	Slightly perfumed	pH (concentrate)	12.9
Active Ingredient	Sodium hypochlorite 4.6% w/w(Available Chlorine 4.4% w/w)	Dilution	Hospital Grade Disinfectant – 5000ppm Infection Control cleaning - See Directions for Use
Use by date (neat):	1 year		

The above data is typical of normal production and should not be taken as a specification.

Product	Pack size	SKU Code	Availability
Divercleanse	12 x 750ml	HH14333	AU & NZ
Divercleanse	2 x 5L	HH14336	AU & NZ

Safe handling and storage information

Full guidance on the handling and disposal of this product is provided in a separate Safety Data Sheet.

Store in original container. Hard surface disinfectant only. Not to be used on skin. Not intended to be used on medical devices. Do not mix with detergents or other chemicals. Store below 25°C. Discard diluted solutions after use.

Under recommended conditions of use, Divercleanse is highly versatile and is suitable on most washroom surfaces such as shower recesses, tiles and toilets, as well as drains and waste pipes, refuse receptacles and bins. Divercleanse can also to remove stains from items such as tea and coffee urns and dish cloths. Divercleanse contains chlorine. Always spot test and ensure surface suitability before use. May discolour fabrics and surfaces. Do not use on enamel, laminates or porcelain if cracked or worn.

Safety Reminder

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use, and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDSs are available online at www.diverse.com or by calling Toll free: Australia, 1800 647 779 or New Zealand, 0800 803 615.

For additional information, please contact us at:
Diversey Australia Pty Ltd Toll free: 1800 647 779, Diversey New Zealand Ltd Toll free: 0800 803 615 www.diverse.com

© 2023 Diversey, Inc. All Rights Reserved.